




HOUSEWARE  
**SWAY**

**DESIGNER** Chan Pingjuan





OpenDesign

[www.downloadopendesign.com](http://www.downloadopendesign.com)

# MATERIALS



Bamboo  
Φ80/110mm



Bungee cord  
Φ1.5\*1000mm  
Black


# TOOLS

Electrodrill


Φ2/3.5/4.5mm




Scissors



Triangle knife



Hammer




Sandpaper



#180 / 320 / 500





Saw




# STEP 1




1. Cut bamboo



2. Cut length 120, width 90 of bamboo




Drill  $\Phi 2/3.5$ mm holes




Tie up the two bamboo with bungee cord


## STEP 2



Cut the two bamboo



Cut the two bamboo



Drill  $\Phi 4.5$ mm holes and tie up the two bamboo with bungee cord

## MAIN BODY COMPLETED

# CONGRATULATION!

Now you got your own houseware

If you meet some problems when building this houseware  
please contact us  
1044208582@qq.com



OpenDesign

[www.downloadopendesign.com](http://www.downloadopendesign.com)