

D OpenDesign


SECRET

designer HUANG SHIYA
LAI QIUHUI


product DRESSING TABLE

update 2016/11/26

Guangdong University of Technology
Opendesign Workshop




MATERIALS




Plybamboo

1330x6100x20mm 2pieces
 900x800x15mm 2pieces
 900x170x15mm 2pieces
 900x610x15mm 1piece
 930x30x10mm 2pieces
 500x30x5mm 2pieces
 310x310x15mm 1piece
 310x30x5mm 1piece




Linen Cloth

1500x4000mm
 1piece




Mirror

310x310x3.5mm
 1piece




Velcro

3000mm




Bamboo

Φ 20x88mm 1 piece
 Φ 20x86mm 1 piece



Bamboo stick

Φ 15x50mm
 4 pieces



Leather

580x200mm
 1 piece




TOOLS



Electrodrill

Φ 12/10/8/6/5/4/3/2mm



Chainsaw



Washer

Φ 6mm




Magnet

Φ 20mm 2pieces




Screwdriver



Sewing machine



File



Ruler




Screw

- ① Φ 4x30mm 24 pieces
- ② Φ 3x30mm 4 pieces
- ③ Φ 4x15mm 1 piece



Screw

- ④ Φ 6x40mm 2pieces
- ⑤ Φ 6x30mm 2pieces



Scissor



Compasses






Pencil





Glue





PARTS




PARTS




drill $\Phi 8\text{mm}$ holes on the plywood, but not go through.
drill $\Phi 2\text{mm}$ holes on the $\Phi 8\text{mm}$ holes.





PARTS



PARTS



The rest of the fillet radius is 20 mm.




drill $\Phi 10$ mm and $\Phi 12$ mm
deep 3mm holes at the \otimes
places.


drill $\Phi 5$ mm and $\Phi 8$ mm
holes on the $\Phi 10$ mm
and $\Phi 12$ mm holes.




PARTS



ASSEMBLY







Storage bag free movement on the beam.



Cloth cover on the bracket and fixed.



PARTS



Cut the linen cloth.



D OpenDesign


SECRET

designer HUANG SHIYA
LAI QIUHUI


product DRESSING TABLE

update 2016/11/26

Guangdong University of Technology
Opendesign Workshop




ASSEMBLY



Put the linen cloth together with a sewing machine.




ASSEMBLY





③ screws twist into H, mirror and H were stained with glue.




ASSEMBLY





Mounting Screw①



Mounting Screw①




(1)+(2)
(1)+(2) and Mounting Screw⑤




F and j use screw② should be fixed.
E and K use screw② should be fixed.



ASSEMBLY





Mounting screw④



Mirror placed between beams, rotated 90° degrees the fixed and can move the mirror.




PARTS



Put the bamboosticks into the bamboo .



ASSEMBLY






Magnet screws for final fixed.

Congratulations, the dressing is prepared!



ASSEMBLY



Sew velcro on skin.

